



Polaris Ranger Side Steps & Nerf Bars Installation

1. Identify the passenger and driver side of steps/nerf bars. Front of steps/nerf bars is easily identifiable by looking at the mount that is closest to the bend in the pipe. The end that has the mount closest to the bend is the front of the steps/nerfs meaning this faces the hood or front of your Polaris.
2. Using your steps/nerf bars line up with the factory bolts that you will be removing. You will be taking out 4 bolts on each side from your Polaris skid plate. 2 on each side will also have a large “saucer” washer” that will be **reused** when mounting your Ranch Armor steps/nerf bars.
3. Hold your steps/nerf bars up to the underbelly of your Polaris Ranger skid plate aligning the laser-cut holes from your steps/nerf bars brackets with the factory holes on your Polaris. *It is MUCH easier if you have someone helping you do this, or use a floor jack to help hold the steps on one side in place while you attach the bolts to secure it.*
4. After lining up your nerfs/side steps use the 2 large (on each side) “saucer” washers to line up and self-center the nerf/side steps bracket as well as included hardware (1x Type F Bolt and 1x Washer) to attach them to the frame. WE HIGHLY RECOMMEND not tightening all the way until ALL 4 bolts are holding the steps/nerf bars in place, on each side.
5. Finally, do a check for a snug/tight fit. You should have no play in the attachment points.

If you have any questions you are always welcome to reach out to us. Visit <http://www.Texas-Outdoors.com> for more Polaris Ranger Accessories.